



| | Original | Recharge | Original | Recharge |
|--|----------|----------|----------|---------------|
| | INT | | | Power |
| | Return | | | Back / Return |
| | Up | | | Up |
| | Down | | | Down |
| | Left | | | Left |
| | Right | | | Right |
| | M | | | OK |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

