



Original	Recharge
TIMER Timer	SHIFT + SLEEP Shift + Sleep / Timer
SLEEP Sleep	SLEEP Sleep / Timer
MONO TUNER Mono Tuner	MEDIA DISPLAY Display / Media
CLOCK Clock	OPT-TOOLS SETUP Setup / OPT /
CD EDIT/CHECK CD Edit/Check	LIST SMART Smart / List
PRGM PRGM	PROGRAM TV/RADIO TV/Radio /
RANDOM/REPEAT Random/Repeat	SHIFT + APP REPEAT Shift + Green / APP /
RANDOM/REPEAT Random/Repeat	SHIFT + Prime Video RANDOM Shift + Blue / Prime
1 1	TV 1 1
2 2	DVD 2 2
3 3	CD - STB 3 3
DECK1/2 TAPE Tape/Deck1/2	NETFLIX SEARCH Red / Netflix / Search
4 4	VIDEO 4 4
5 5	TAPE 5 5
6 6	TUNER 6 6
BAND TUNER Tuner/Band	APP REPEAT Green / APP / Repeat
7 7	AUX - HDD 7 7

Original	Recharge
8 8	USB 8 8
9 9	BLUETOOTH 9 9
AUX VIDEO Video/AUX	YouTube REPEAT A-B Yellow / YouTube / Repeat
0 0	HDMI - BAT 0 0
+10 +10	GUIDE EPG Guide / EPG / -/-
CD CD	Prime Video RANDOM Blue / Prime Video / Random
Disc Direct Play 1	SHIFT + TV 1 Shift + 1
Disc Direct Play 2	SHIFT + DVD 2 Shift + 2
Disc Direct Play 3	SHIFT + CD - STB 3 Shift + 3
Disc Direct Play 4	SHIFT + VIDEO 4 Shift + 4
Disc Direct Play 5	SHIFT + TAPE 5 Shift + 5
Disc Direct Play 6	SHIFT + TUNER 6 Shift + 6
Disc Direct Play 7	SHIFT + AUX - HDD 7 Shift + 7
SURROUND Surround	SHIFT + SURROUND Shift + Eject / Surround
MANUAL SELECT Manual Select	OK OK
DOLBY PRO LOGIC Dolby Pro Logic	TITLE SOUND Sound / Title
T-BASS T-Bass	LANG I/II AUDIO Audio / Lang I/II





Original		Recharge		Original		Recharge	
	GEQ		Subtitle / EQ		Vol-		Vol-
	Karaoke		Info / Angle		Power		Power
	Open/Close		Eject / Surround		Stop / Down / Clear / Preset-		Down
	Rec/Rec Mute		Rec / Rec Mode		Stop / Down / Clear / Preset-		Stop / Hold
	Play / Up /		Play / Slow		Stop / Down / Clear / Preset-		Shift + I<< / Preset-
	Play / Up /		Shift + >>I / Preset+		Stop / Down / Clear / Preset-		Exit / Cancel / Clear
	Play / Up /		Up				
	Vol+		Vol+				
	Pause / Set		Pause / Step / Freeze				
	<< / I<< / Left / Tuning Down		Left				
	<< / I<< / Left / Tuning Down		I<< / Preset-				
	<< / I<< / Left / Tuning Down		Shift + << /				
	>> / >>I / Right / Tuning Up		Right				
	>> / >>I / Right / Tuning Up		>> / Preset+				
	>> / >>I / Right / Tuning Up		Shift + >> /				

