







































































Original		Recharge		Original		Recharge	
	Power		Power		Volume+		Vol+
	Rec		Rec / Rec Mode		Mute		Mute / Dimmer
	Pause		Pause / Step / Freeze		CH/PG+		CH- / Page-
	Stop		Stop / Hold		Volume-		Vol-
	<<		<< / Tune-		CH/PG-		CH+ / Page+
	Play		Play / Slow		Recorded TV		Display / Media
	>>		>> / Tune+		Guide		Guide / EPG / -/-
	I<		I<< / Preset-		Live TV		TV/Radio /
	>I		>>I / Preset+		Format / DVD		D.Menu / Top
	Back		Back / Return		1		1
	Start (Windows)		Smart / List		2		2
	i More		Info / Angle		3		3
	Up		Up		4		4
	Left		Left		5		5
	OK		OK		6		6
	Right		Right		7		7
	Down		Down		8		8





Original	Recharge	Original	Recharge
	9		9
	*		Shift + Guide / EPG / -/-
	0		0
	#		Shift + Fav / Marker / PC
	Clear		Exit / Cancel / Clear
	[T] Teletext		Text / Goto
	Enter		Fav / Marker / PC
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

Original	Recharge

