







































































Original	Recharge	Original	Recharge
 Power	 Power	 9	 9
 ATV	 Setup / OPT /	 Inf/Me	 Info / Angle
 DTV	 D.Menu / Top	 0	 0
 3D	 Display / Media	 Rec/Del	 Back / Return
 HDMI	 Shift + 0	 Freeze	 Shift + Pause / Step /
 Input	 AV / Input / RDS	 EPG	 Guide / EPG / -/-
 Sound	 Sound / Title	 MTS	 Text / Goto
 Picture	 Picture / Format	 Mute	 Mute / Dimmer
 Zoom	 Zoom / Size	 Vol+	 Vol+
 1	 1	 Prog+	 CH+ / Page+
 2	 2	 Vol-	 Vol-
 3	 3	 Prog-	 CH- / Page-
 4	 4	 Up	 Up
 5	 5	 Left	 Left
 6	 6	 OK	 OK
 7	 7	 Right	 Right
 8	 8	 Menu	 Menu / Home





Original	Recharge	Original	Recharge
	Down		Down
	Exit		Exit / Cancel / Clear
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Play		Play / Slow
	Stop		Stop / Hold
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Pause		Pause / Step / Freeze
	Rec		Rec / Rec Mode
	<<		<< / Tune-
	>>		>> / Tune+
	Index		Subtitle / EQ
	FAV		Fav / Marker / PC
	List		Smart / List
			Radio
			TV/Radio /

