
























































Original	Rechange
 Power	 Power
 Mute	 Mute / Dimmer
 TV/RAD	 TV/Radio /
 www	 Sleep / Timer
 PIP	 Zoom / Size
 Grid	 D.Menu / Top
 Swap	 Back / Return
 Sub ch	 Setup / OPT /
 P/Pg+	 CH+ / Page+
 RCL	 Display / Media
 Vol+	 Vol+
 P/Pg-	 CH- / Page-
 i	 Info / Angle
 Vol-	 Vol-
 FAV	 Fav / Marker / PC
 Check	 Smart / List
 Message	 Eject / Surround

Original	Rechange
 EPG	 Guide / EPG / -/-
 Up	 Up
 Menu	 Menu / Home
 Left	 Left
 OK	 OK
 right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5



