



Original	Rechange	Original	Rechange
 Standby	 Power	 Rec	 Rec
 TV / STB	 AV	 Menu	 Menu
 Mute	 Mute	 Exit	 Exit
 Recall	 Back	 CH+ / PG+	 Ch +
 TTXT	 Text	 CH- / PG-	 Ch -
 Signal	 Smart	 Vol+	 Vol +
 Capture	 3D	 Vol-	 Vol -
 Subt	 Subt	 Up	 Up
 Timer	 Shift + AV	 Left	 Left
 I<<	 I<<	 OK	 Ok
 <<	 <<	 Right	 Right
 >>	 >>	 Down	 Down
 >>I	 >>I	 Find	 Shift + TV/R
 USB File	 Media	 EPG	 Guide
 Play / Pause	 Play	 Info	 Info
 Play / Pause	 Pause	 FAV	 Pre Ch
 Stop	 Stop	 SAT List	 List



