





































































Original		Rechange		Original		Rechange	
	Power		Power		[Z]		Format
	Open/Close		Eject		Camera		3D
	[ ]X		Smart		(Z)))))		Dual
	EQ		Media		Time		AV
	Mute		Mute		Prog		Sleep
	→[ ]←		Subt		Setup/Mem		Options
	1		1		Title		List
	2		2		Menu/PBC		Menu
	3		3		Return/Exit		Back
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right/FAV+		Right
	7		7		Left/FAV-		Left
	8		8		Enter		Ok
	9		9		Function		Pre Ch
	0		0		Tv/Radio		TV/R
	+10		Guide		DVD		D. Menu



