







































































| Original   | Recharge   |
|--|--|
|  POWER  |  Power    |
|  SOURCE |  AV       |
|  EXIT   |  Exit     |
|  MENU   |  Menu     |
|  AUDIO  |  Dual     |
|  1      |  1        |
|  2      |  2        |
|  3      |  3        |
|  4      |  4        |
|  5      |  5        |
|  6     |  6       |
|  7    |  7      |
|  8    |  8      |
|  9    |  9      |
|  0    |  0      |
|  FAV  |  Pre Ch |
|  MUTE |  Mute   |

| Original   | Recharge   |
|--|--|
|  PIC MODE   |  Shift + Format |
|  TEXT       |  Text           |
|  TV / RADIO |  TV/R           |
|  OK         |  Ok             |
|  UP / CH+   |  Up             |
|  DOWN / CH- |  Down           |
|  RIGHT      |  Right          |
|  LEFT       |  Left           |
|  PAGE UP    |  Ch +           |
|  PAGE DOWN  |  Ch -           |
|  VOL+       |  Vol +          |
|  VOL-     |  Vol -        |
|  SLEEP    |  Sleep        |
|  SUB.     |  Subt         |
|  RECALL   |  Back         |
|  RED      |  Red          |
|  GREEN    |  Green        |





| Original |           | Recharge |         | Original | Recharge |
|----------|-----------|----------|---------|----------|----------|
|          | YELLOW    |          | Yellow  |          |          |
|          | BLUE      |          | Blue    |          |          |
|          | STOP      |          | Stop    |          |          |
|          | PAUSE     |          | Pause   |          |          |
|          | REC       |          | Rec     |          |          |
|          | REW       |          | <<      |          |          |
|          | PLAY      |          | Play    |          |          |
|          | FWD       |          | >>      |          |          |
|          | SAT       |          | Smart   |          |          |
|          | EPG       |          | Guide   |          |          |
|          | HELP      |          | D. Menu |          |          |
|          | V. FORMAT |          | Format  |          |          |
|          | INFO      |          | Info    |          |          |
|          | T / S     |          | List    |          |          |
|          | POS.      |          | Media   |          |          |
|          |           |          |         |          |          |
|          |           |          |         |          |          |

