






















































Original		Rechange		Original		Rechange	
	Power		Power		Vol+		Vol +
	Input		AV		Vol-		Vol -
	Settings/Q.Men		D. Menu		FAV		Pre Ch
	Info		Info		3D		3D
	[?]		Dual		Mute		Mute
	1		1		P+		Ch +
	2		2		P-		Ch -
	3		3		Recent		Format
	4		4		Smart		Smart
	5		5		My APPS		Media
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Right		Right
	0		0		Down		Down
	Guide		Guide		Back		Back
	Q.View		List		Live Menu		Menu





Original		Recharge		Original	Recharge
	Exit		Exit		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Text		Text		
	T.Opt		Options		
	Sleep		Sleep		
	Stop / Live TV		Stop		
	Play		Play		
	Pause		Pause		
	<<		<<		
	>>		>>		
	Rec		Rec		
	Subtitle		Subt		
	AD/*		Shift + Subt		
	Tv/Rad		TV/R		

