



Original	Recharge	Original	Recharge
 Power	 Power	 Info	 Info / Angle
 Mute	 Mute / Dimmer	 [II]	 Shift + Audio / Lang I/II
 Red	 Red / Netflix / Search	 Source/Av	 AV / Input / RDS
 Green	 Green / APP / Repeat	 Up	 Up
 Yellow	 Yellow / YouTube / Repeat	 Left	 Left
 Blue	 Blue / Prime Video / Random	 Ok	 OK
 <</[Timer]	 << / Tune-	 Right	 Right
 >>/[≡?]	 >> / Tune+	 Down	 Down
 I<</[≡↓]	 I<< / Preset-	 Epg	 Guide / EPG / -/-
 >>I/[≡...]	 >>I / Preset+	 Exit	 Exit / Cancel / Clear
 Play	 Play / Slow	 Vol+	 Vol+
 Pause	 Pause / Step / Freeze	 Fav	 Fav / Marker / PC
 Stop	 Stop / Hold	 Ch+	 CH+ / Page+
 [≡i]	 Shift + Info / Angle	 Vol-	 Vol-
 Text	 Text / Goto	 Rec	 Rec / Rec Mode
 Subtitle	 Subtitle / EQ	 Ch-	 CH- / Page-
 Freeze	 Shift + Pause / Step / Freeze	 1	 1



