



Original		Recharge		Original		Recharge	
	Power		Power		Yellow		Yellow
	Play		Play		Blue		Blue
	Stop		Stop		CH+		Ch +
	Pause		Pause		CH-		Ch -
	<<		<<		Vol+		Vol +
	>>		>>		Vol-		Vol -
	I<<		I<<		Menu		Menu
	>>I		>>I		Source		AV
	TV/TXT		Text		DVB		Smart
	Cancel		Back		Exit		Exit
	Reveal		Eject		OK		Ok
	Hold		Media		Up		Up
	Size		3D		Down		Down
	Subpage		D. Menu		Right		Right
	Index		List		Left		Left
	Red		Red		1		1
	Green		Green		2		2



