




























































Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 Back	 Back
 P.Mode	 Shift + Format
 S.Mode	 Dual
 Sleep	 Sleep

Original	Rechange
 NICAM	 Smart
 Menu	 Menu
 Source	 AV
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Exit	 Exit
 Display	 Info
 Vol +	 Vol +
 Vol -	 Vol -
 List	 List
 Fav List	 Pre Ch
 CH +	 Ch +
 CH -	 Ch -
 TV / Radio	 TV/R





Original		Rechange		Original		Rechange	
	CPG		Media				
	Aspect		Format				
	Freeze		Pause				
	Index		D. Menu				
	Cancel		Shift + Back				
	Subpage		Subt				
	Text		Text				
	Reveal		Options				
	Size		3D				
	Hold		Stop				
	Mix		Rec				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Cyan		Blue				

