







































































| Original | | Rechange | | Original | | Rechange | |
|---|---------------|---|---------------|---|-----------|---|-------|
|  | Power |  | Power |  | 9 |  | 9 |
|  | P.Mode |  | Format |  | 0 |  | 0 |
|  | S.Mode |  | Shift + Dual |  | Source |  | AV |
|  | Mute |  | Mute |  | Recall |  | Back |
|  | Auto |  | Smart |  | CH+ |  | Ch + |
|  | -/-- |  | Shift + Guide |  | CH- |  | Ch - |
|  | Sleep |  | Sleep |  | Up |  | Up |
|  | Display |  | Info |  | Left |  | Left |
|  | Audio / Nicam |  | Dual |  | Enter |  | Ok |
|  | 1 |  | 1 |  | Right |  | Right |
|  | 2 |  | 2 |  | Down |  | Down |
|  | 3 |  | 3 |  | Vol+ |  | Vol + |
|  | 4 |  | 4 |  | Vol- |  | Vol - |
|  | 5 |  | 5 |  | TV Menu |  | Menu |
|  | 6 |  | 6 |  | Exit |  | Exit |
|  | 7 |  | 7 |  | << / Text |  | << |
|  | 8 |  | 8 |  | << / Text |  | Text |



