



Original	Rechange	Original	Rechange
MUTE	Mute	MUTE	Mute
POWER	Power	POWER	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	GUIDE	Guide
AV	AV	AV	AV
MENU	Menu	MENU	Menu
OK	Red	A	Red
OK	OK	OK	Ok

Original	Rechange	Original	Rechange
P.P Green	B Green	P.P	Pre Ch
ANALOG Yellow	C Yellow	Analog	Smart
Blue	D Blue	Up	Up
P+	Ch +	P-	Ch -
P-	Down	Right	Right
Vol+	Vol +	Vol-	Vol -
Vol-	Left	Recall	Back
Sleep	Sleep	Status	3D
Tv/TXT	Text		





Original	Recharge	Original	Recharge
 Stop	 Stop		
 Reveal	 Media		
 Size	 Format		
 Mix	 Options		
 Index	 Info		
 Subcode	 Subt		
 Cancel	 Shift + Back		

