






















	Original	Rechange
	Power	 Power
	Input Digital 1	 1
	Input Digital 2	 2
	Vol+	 Vol +
	Vol-	 Vol -
	Fade Muting	 Mute
	Analog	 Smart
	Subwoofer+	 Ch +
	Subwoofer-	 Ch -
	Center+	 Right
	Center-	 Left
	Surround+	 Up
	Surround-	 Down
	Surround Mode	 4
	Surround Mode	 5
	Off	 6
	Dimmer	 Options

	Original	Rechange
	DRC	 TV/R

