



| Original  |               | Rechange  |         | Original  |               | Rechange  |              |
|---|---------------|---|---------|---|---------------|---|--------------|
|    | Power         |    | Power   |    | Return / Text |    | Shift + Back |
|    | Mute          |    | Mute    |    | Subtitle      |    | Subt         |
|    | Red / Eject   |    | Red     |    | Display       |    | Shift + Info |
|    | Red / Eject   |    | Eject   |    | Menu / Info   |    | Info         |
|    | Green / Title |    | Green   |    | Menu / Info   |    | D. Menu      |
|    | Yellow / DVD  |    | Yellow  |    | Menu          |    | Menu         |
|    | Yellow / DVD  |    | Options |    | Up            |    | Up           |
|    | Blue / A-B    |    | Blue    |    | Source        |    | AV           |
|    | <</[≡o]       |    | <<      |    | Left          |    | Left         |
|   | >>/[≡?]       |   | >>      |   | OK            |   | Ok           |
|  | l<</[≡+]      |  | l<<     |  | Right         |  | Right        |
|  | >>l/[≡..]     |  | >>l     |  | EPG           |  | Guide        |
|  | Play          |  | Play    |  | Down          |  | Down         |
|  | Pause         |  | Pause   |  | Exit          |  | Exit         |
|  | Stop          |  | Stop    |  | Vol+          |  | Vol +        |
|  | Angle / [≡i]  |  | Smart   |  | FAV           |  | Pre Ch       |
|  | Return / Text |  | Text    |  | CH+           |  | Ch +         |





| Original    |               | Recharge    |       | Original | Recharge |
|-------------|---------------|-------------|-------|----------|----------|
| VOL -       | Vol-          | VOL -       | Vol - |          |          |
| REP         | REP           | REC MODE    | Rec   |          |          |
| CH -        | CH-           | CH -        | Ch -  |          |          |
| 1           | 1             | 1           | 1     |          |          |
| 2           | 2             | 2           | 2     |          |          |
| 3           | 3             | 3           | 3     |          |          |
| 4           | 4             | 4           | 4     |          |          |
| 5           | 5             | 5           | 5     |          |          |
| 6           | 6             | 6           | 6     |          |          |
| 7           | 7             | 7           | 7     |          |          |
| 8           | 8             | 8           | 8     |          |          |
| 9           | 9             | 9           | 9     |          |          |
| AUDIO       | Audio         | SOUND DUAL  | Dual  |          |          |
| 0           | 0             | 0           | 0     |          |          |
| RECALL/GOTO | Recall / Goto | RETURN BACK | Back  |          |          |
|             |               |             |       |          |          |
|             |               |             |       |          |          |
|             |               |             |       |          |          |
|             |               |             |       |          |          |
|             |               |             |       |          |          |

