



Original	Recharge	Original	Recharge
Power	Power	Menu	Menu
Mute	Mute	EPG	Guide
1	1	Exit	Exit
2	2	Up / CH + / I<<	Up
3	3	Down / CH - / >>I	Down
4	4	Right / Vol +	Right
5	5	Left / Vol -	Left
6	6	OK	Ok
7	7	Up / CH + / I<<	I<<
8	8	Down / CH - / >>I	>>I
9	9	Up / CH + / I<<	Ch +
0	0	Down / CH - / >>I	Ch -
FAV	Shift + Pre Ch	Left / Vol -	Vol -
Recall	Pre Ch	Right / Vol +	Vol +
Game	Media	Red / Zoom	Red
Auto	Smart	Green / Lan/Audio	Green
Info	Info	Yellow /	Yellow

Original	Recharge	Original	Recharge
Power	Power	Menu	Menu
Mute	Mute	EPG	Guide
1	1	Exit	Exit
2	2	Up / CH + / I<<	Up
3	3	Down / CH - / >>I	Down
4	4	Right / Vol +	Right
5	5	Left / Vol -	Left
6	6	OK	Ok
7	7	Up / CH + / I<<	I<<
8	8	Down / CH - / >>I	>>I
9	9	Up / CH + / I<<	Ch +
0	0	Down / CH - / >>I	Ch -
FAV	Shift + Pre Ch	Left / Vol -	Vol -
Recall	Pre Ch	Right / Vol +	Vol +
Game	Media	Red / Zoom	Red
Auto	Smart	Green / Lan/Audio	Green
Info	Info	Yellow /	Yellow



Play/Pause



Original	Rechange	Original	Rechange
TEXT Blue / Text	Blue		
ZOOM Red / Zoom	Eject		
LAN/AUDIO Green / Lan/Audio	Dual		
PLAY/PAUSE Yellow /	Play		
PLAY/PAUSE Yellow /	Pause		
TEXT Blue / Text	Text		
TV/RADIO << / Tv/Radio	<<		
TV/RADIO << / Tv/Radio	TV/R		
SUBTITLE >> / Subtitle	>>		
SUBTITLE >> / Subtitle	Subt		

Original	Rechange

