











































































































Original	Recharge	Original	Recharge
 Power	 Power	 Stop/Reveal	 Stop / Hold
 Mute	 Mute / Dimmer	 <</Hold	 << / Tune-
 Red	 Red / Netflix / Search	 >>/Subpage	 >> / Tune+
 Green	 Green / APP / Repeat	 I<</Size	 I<< / Preset-
 Yellow	 Yellow / YouTube / Repeat	 >>I/Cancel	 >>I / Preset+
 Blue	 Blue / Prime Video / Random	 Info	 Info / Angle
 EPG	 Guide / EPG / -/--	 Input	 AV / Input / RDS
 Home	 Shift + Home / Menu /	 Menu	 Menu / Home
 Rec	 Rec / Rec Mode	 Exit	 Exit / Cancel / Clear
 Setup	 Setup / OPT /	 Up	 Up
 Sub-T	 Subtitle / EQ	 Down	 Down
 Mouse	 Smart / List	 Right	 Right
 T-Shift	 Zoom / Size	 Left	 Left
 Tv/Radio	 TV/Radio /	 OK	 OK
 Text	 Text / Goto	 Vol+	 Vol+
 Play/Index	 Play / Slow	 Vol-	 Vol-
 Pause/Mix	 Pause / Step / Freeze	 Audio	 Audio / Lang I/II





Original	Recharge
 Sleep	 Sleep / Timer
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Shift + Guide / EPG / -/--
 Recall	 Back / Return
 P.Mode	 Picture / Format
 FAV	 Fav / Marker / PC

Original	Recharge
 S.Mode	 Sound / Title

