











































































	Original	Recharge	Original	Recharge
	Standby			Right
	Rec PVR			Left
	PVR List			Ok
	Mute			Vol +
	EPG			Vol -
	Audio			1
	Info			2
	TTX			3
	Subtitle			4
	Menu			5
	Exit			6
	Favourite			7
	Tv/Radio			8
	CH+			9
	CH-			0
	Up			Recall
	Down			Goto
				Back
				AV





	Original	Recharge	Original	Recharge
	<<			<<
	>>			>>
	l<<			l<<
	>>l			>>l
	Play			Play
	Pause			Pause
	Stop			Stop
	Repeat			Shift + Text
	Red			Red
	Green			Green
	Yellow			Yellow
	Blue			Blue

