



































































| Original | Recharge | Original | Recharge |
|--|--|---|---|
|  Power |  Power |  Green |  Green / APP / Repeat |
|  Stop |  Stop / Hold |  Yellow |  Yellow / YouTube / Repeat |
|  Pause |  Pause / Step / Freeze |  Blue |  Blue / Prime Video / Random |
|  Rec |  Rec / Rec Mode |  i+/Info |  Info / Angle |
|  << |  << / Tune- |  Options |  Setup / OPT / |
|  Play |  Play / Slow |  Up |  Up |
|  >> |  >> / Tune+ |  Left |  Left |
|  Zoom / Size |  Zoom / Size |  OK |  OK |
|  D.Menu / Top |  D.Menu / Top |  Right |  Right |
|  Picture / Format |  Picture / Format |  Back |  Back / Return |
|  Tv Guide |  Guide / EPG / -/-- |  Down |  Down |
|  Search |  Shift + Red / Netflix / Search |  Multiview |  Display / Media |
|  Sources |  AV / Input / RDS |  Vol+ |  Vol+ |
|  Smart Tv |  Smart / List |  List |  Shift + Smart / List |
|  Home |  Menu / Home |  CH+ |  CH+ / Page+ |
|  Exit/Tv |  Exit / Cancel / Clear |  Vol- |  Vol- |
| Red | Red / Netflix / Search | Mute | Mute / Dimmer |





| Original | Rechange | Original | Rechange |
|----------|---------------|----------|----------|
| CH- | CH / Page- | | |
| 1 | 1 | | |
| 2 | 2 | | |
| 3 | 3 | | |
| 4 | 4 | | |
| 5 | 5 | | |
| 6 | 6 | | |
| 7 | 7 | | |
| 8 | 8 | | |
| 9 | 9 | | |
| Subtitle | Subtitle / EQ | | |
| 0 | 0 | | |
| Text | Text / Goto | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

