

































































Original	Recharge	Original	Recharge
	Power		Power
	SAT		AV
	Mute		Mute
	PGUP		Shift + Ch +
	PGDN		Shift + Ch -
	FAV +		Shift + Right
	FAV -		Shift + Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SUB		Subt
	Audio		Dual
	TV / R		TV/R
	Sleep		Sleep
	TXT		Text
	RCL		Back
	Menu		Menu
	Info		Info
	VL +		Vol +
	VL -		Vol -
	Up		Up
	Right		Right
	Down		Down





Original		Rechange	
	Left		Left
	OK		Ok
	CH +		Ch +
	CH -		Ch -
	EPG		Guide
	FAV		Pre Ch
	<<		<<
	>>		>>
	Pause		Pause
	I<<		I<<
	>>I		>>I
	Rec		Rec
	Play / Pause		Play
	Stop		Stop
	USB		Media
	MP3		Smart
	JPEG		Shift + Media

Original		Rechange	
	PVR List		List
	Still >I<		Shift + Stop
	Zoom		Eject
	Edit		Options
	Exit		Exit
	A-B		Shift + Text
	T.S.		3D
	GOTO		D. Menu

