

















































	Original	Rechange	Original	Rechange
	Power			Recall
	Mute			Back
	[i+]/[?]			List
	A/B/[+]			Sleep
	Input/[+]			Vol +
	[ ]			Vol -
	1			Ch +
	2			Ch -
	3			Dual
	4			Menu
	5			Up
	6			Left
	7			Ok
	8			Right
	9			Down
	0			Text
	-/--			Red
				Green



