







































































| Original | | Rechange | | Original | | Rechange | |
|---|--------|---|-------------------|---|-------------|---|-----------------------|
|  | Power |  | Power |  | Vol- |  | Vol- |
|  | Source |  | AV / Input / RDS |  | i/Info |  | Info / Angle |
|  | 1 |  | 1 |  | PR- |  | CH- / Page- |
|  | 2 |  | 2 |  | Menu |  | Menu / Home |
|  | 3 |  | 3 |  | Up |  | Up |
|  | 4 |  | 4 |  | Q.Menu |  | D.Menu / Top |
|  | 5 |  | 5 |  | Left |  | Left |
|  | 6 |  | 6 |  | OK |  | OK |
|  | 7 |  | 7 |  | Right |  | Right |
|  | 8 |  | 8 |  | Back |  | Back / Return |
|  | 9 |  | 9 |  | Down |  | Down |
|  | TV |  | TV/Radio / |  | Exit |  | Exit / Cancel / Clear |
|  | 0 |  | 0 |  | World |  | Smart / List |
|  | Recall |  | Fav / Marker / PC |  | Music Photo |  | Display / Media |
|  | Vol+ |  | Vol+ |  | Guide |  | Guide / EPG / -/-- |
|  | Mute |  | Mute / Dimmer |  | */o |  | Setup / OPT / |
|  | PR+ |  | CH+ / Page+ |  | */o.. |  | Zoom / Size |





| Original | Recharge | Original | Recharge |
|--|---|----------|----------|
|  ≡/Text |  Text / Goto | | |
|  Red |  Red / Netflix / Search | | |
|  Green |  Green / APP / Repeat | | |
|  Yellow |  Yellow / YouTube / Repeat | | |
|  Blue |  Blue / Prime Video / Random | | |
|  Lang |  Audio / Lang I/II | | |
|  [≡].. |  Subtitle / EQ | | |
|  [-O-] |  Picture / Format | | |
|  << |  << / Tune- | | |
|  Pause |  Pause / Step / Freeze | | |
|  >> |  >> / Tune+ | | |
|  Rec |  Rec / Rec Mode | | |
|  Play |  Play / Slow | | |
|  Stop |  Stop / Hold | | |
| | | | |
| | | | |
| | | | |

