

























































	Original	Rechange		Original	Rechange
	Power		Power		CH+
	Source		AV		CH-
	Sleep		Sleep		Down
	Mute		Mute		Right
	1		1		Left
	2		2		Vol-
	3		3		Vol+
	4		4		Enter
	5		5		Red
	6		6		Green
	7		7		Yellow
	8		8		Blue
	9		9		Info
	0		0		EPG
	-/--		Shift + Guide		Menu
	Recall		Pre Ch		Nicam
	Up		Up		FAV+
					>>





Original	Recharge
 FAV-	 <<
 TXT	 Text
 Edit/Group	 Options
 Index	 Back
 Lang/Audio	 Dual
 TV/Radio	 TV/R
 Subtitle	 Subt
 Subpage	 Shift + Subt
 Size	 Format
 Hold	 3D
 Still	 Exit
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual

Original	Recharge

