
































































































Original		Recharge		Original		Recharge	
	Standby		Power		Source / AV		AV
	TV / Radio		TV/R		Info		Info
	TV Guide		Guide		Up		Up
	Mute		Mute		Right		Right
	ATV		Shift + Smart		Down		Down
	USB		Media		Left		Left
	DVD		Smart		OK		Ok
	Eject		Eject		Menu		Menu
	Rec		Rec		Exit		Exit
	Rec List		Shift + Rec		1		1
	I<<		I<<		2		2
	>>I		>>I		3		3
	Stop		Stop		4		4
	<<		<<		5		5
	>>		>>		6		6
	Play / Pause		Play		7		7
	Play / Pause		Pause		8		8





Original	Recharge
 9	 9
 0	 0
 Recall	 Back
 Fav	 Pre Ch
 Vol +	 Vol +
 Vol -	 Vol -
 Subtitle	 Subt
 Aspect	 Format
 Audio	 Dual
 Sleep	 Sleep
 CH +	 Ch +
 CH -	 Ch -
 Red / Goto	 Red
 Green / A-B	 Green
 Yellow / Angle	 Yellow
 Blue / Repeat	 Blue
 Blue / Repeat	 Shift + Text

Original	Recharge
 D.Dis	 Shift + Info
 Zoom	 Shift + Eject
 Size	 3D
 Display (Power)	 Shift + Power
 Text / D.Setup	 Text
 Text / D.Setup	 Options
 Index / D.Menu	 D. Menu
 Reveal / Title	 List
 Hold	 Shift + Pause

