



| Original   | Recharge  | Original   | Recharge  |
|--|---|--|---|
|  Power    |  Power                       |  Green  |  Green / APP / Repeat        |
|  Mute     |  Mute / Dimmer               |  Sub    |  Subtitle / EQ               |
|  Stop     |  Stop / Hold                 |  Yellow |  Yellow / YouTube / Repeat   |
|  Play     |  Play / Slow                 |  Sleep  |  Sleep / Timer               |
|  Pause    |  Pause / Step / Freeze       |  Blue   |  Blue / Prime Video / Random |
|  <<       |  << / Tune-                  |  Timer  |  Shift + Sleep / Timer       |
|  >>       |  >> / Tune+                  |  Menu   |  Menu / Home                 |
|  Rec      |  Rec / Rec Mode              |  i      |  Info / Angle                |
|  USB      |  Shift + USB 8               |  Up     |  Up                          |
|  I<<      |  I<< / Preset-               |  Left   |  Left                        |
|  >>I      |  >>I / Preset+               |  OK     |  OK                          |
|  Help    |  List / Smart               |  Right |  Right                      |
|  FAV    |  Shift + FAV / Marker / PC |  Exit |  Exit / Cancel / Clear     |
|  Audio  |  Audio / Lang I/II         |  Down |  Down                      |
|  Option |  Setup / OPT               |  Back |  Back / Return             |
|  Red    |  Red / Netflix / Search    |  Vol+ |  Vol+                      |
|  TTX    |  Text / Goto               |  EPG  |  Guide / EPG / -/-         |





| Original | Recharge             |
|----------|----------------------|
| CH+      | CH+ / Page+          |
| Vol-     | Vol-                 |
| List     | Shift + Smart / List |
| CH-      | CH- / Page-          |
| 1        | 1                    |
| 2        | 2                    |
| 3        | 3                    |
| 4        | 4                    |
| 5        | 5                    |
| 6        | 6                    |
| 7        | 7                    |
| 8        | 8                    |
| 9        | 9                    |
| Tv/Radio | TV/Radio /           |
| 0        | 0                    |
| Recall   | Fav / Marker / PC    |

| Original | Recharge |
|----------|----------|
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |

