






















































Original	Recharge
 System Power	 Power
 Standby	 Shift + Power
 Sleep	 Sleep
 PHONO	 Shift + 1
 TUNER	 Shift + 2
 CD	 Shift + 3
 MULTI CH IN	 Shift + 4
 V-AUX	 Shift + 5
 CBL / SAT	 Shift + 6
 MD / TAPE	 Shift + 7
 CD-R	 Shift + 8
 DTV	 Shift + 9
 VCR 1	 Shift + Guide
 DVR / VCR2	 Shift + 0
 DVD	 Shift + Pre Ch
 Preset+	 Ch +
 Preset-	 Ch -

Original	Recharge
 A/B/C/D/E	 Smart
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Level	 Media
 Set Menu	 Menu
 Up	 Up
 Left	 Left
 Select	 Ok
 Right	 Right
 Down	 Down
 Test	 Text
 On Screen /	 Info
 Pure Direct	 Guide
 Night	 0
 Straight Effect	 Dual
 Stereo	 1





Original		Recharge		Original		Recharge	
	System Power		Power		2 Tuner		2
	Standby		Shift + Power		3 Tuner		3
	Sleep		Sleep		4 Tuner		4
	Volume +		Vol +		5 Tuner		5
	Volume -		Vol -		6 Tuner		6
	Mute		Mute		7 Tuner		7
	A/B/C/D/E		Smart		8 Tuner		8
	Title Tuner		Media		9 Tuner		9
	Menu Tuner		Menu		0 Tuner		0
	Up Tuner		Up		ENTER Tuner		Pre Ch
	Left Tuner		Left				
	Select Tuner		Ok				
	Right Tuner		Right				
	Down Tuner		Down				
	Return Tuner		Back				
	Display Tuner		Info				
	1 Tuner		1				

