Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
+10	Guide
Function	Menu
Play	Play
Stop	Stop
Pause/Set	Pause
Vol+	Vol +

Original	Replacement
Vol-	Vol -
Disc Direct Play 1	Shift + 1
Disc Direct Play 2	Shift + 2
Disc Direct Play 3	Shift + 3
Disc Direct Play 4	Shift + 4
Disc Direct Play 5	Shift + 5
Clear	Exit
Preset	Info
<<|<<	<<
>>|>>	>>
Sleep	Sleep
Random/Repeat	Text
CD Edit/Check	Pre Ch
PRGM	Options
GEQ	Media
T-Bass	Dual
Timer	AV

Original		Replacement	
BAND	Band	SEARCH TV/R	TV/R
CLOCK	Clock	ECO 3D	3D
MONO TUNER	Mono Tuner	PICTURE FORMAT	Format

Original	Replacement