Mandis shop

Sharp RRMCGA001SJSA

Original	Replacement
On/Standby	Power
CD	Yellow
Tuner/Band	Green
Tape	Red
<</Tuning	<<
>>/Tuning Up	>>
I<</Preset	I<<
>>I/Preset Up	>>I
Play	Play
Stop	Stop
Pause	Pause
Memory	Smart
Clear	Exit
Random/Repeat	Text
Clock	D. Menu
Timer	AV
Sleep	Sleep

Original	Replacement
Treble-	Left
Treble+	Right
Bass-	Down
Bass+	Up
Vol-	Vol -
Vol+	Vol +

https://all-remote-controls.nl/en/Sharp/1063229-2558-replacement-remote-control-for-Sharp-RRMCGA001SJSA.html