Original		Replacement	
	Power		Power
	Sleep	VOD	VOD
	Play		Play
	Pause		Pause
	Stop		Stop
	>>		Fast Forward
	<<		Rewind
MEDIA	Media	MEDIA	MEDIA
MENU	Menu	MENU	MENU
	Input	SRC	SRC
	Info	INFO	INFO
OK	OK	OK	OK
	Up		UP
	Down		DOWN
	Right		RIGHT
	Left		LEFT
	Wide	WIDE	WIDE

Original		Replacement	
	Audio		Audio
	Return	BACK	BACK
	Mute		MUTE
	Vol +		VOL +
	Vol -		VOL -
	CH+		CH +
	CH-		CH -
1	1		1
2	2		2
3	3		3
4	4		4
5	5		5
6	6		6
7	7		7
8	8		8
9	9		9
0	0		0

Original		Replacement		Original	Replacement
–	- -	EPG 1. -/--	- / - - / EPG		
TV	TV	TV/R	TV/ R		
HDMI	HDM	OPT+	OPT+		
ENT	ENT	FAV 2. P/C	P/ C / FAV		
PC	PC	A	Red (A)		
VIDEO	Vi deo	B	Gr een (B)		
COMP	COMP	C	Yel l ow (C)		
MUSIK	Musk	D	Bl ue (D)		