Mandis shop

Philips 996580000536

Original	Replacement
Power	Power
Coax	Red
Play	Play
Pause	Pause
Optical	Green
AUX	Yellow
USB	Blue
I<	I<<
>I	>>I
Vol +	Vol +
Vol -	Vol -
Mute	Mute
Treble+	Ch +
Treble-	Ch -
Bass+	Up
Bass-	Down
Audio Sync -	Left

Original	Replacement
Audio Sync +	Right
Surround Off	Format
Surround On	3D
Sound	Dual
DIM	Media
Night	Smart
Bluetooth	Guide
HDMI ARC	Pre Ch

https://al-remotecontrols.nl/en/Philips/1363-602-replacement-remote-control-for-Philips-996580000536.htm