Mandis shop

REMCON278

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| TV/♫ | TV / Radio | SEARCH TV/R | TV/R |
| MUTE | Mute | MUTE | Mute |
| i | i | DISPLAY INFO | Info |
| ALT | ALT | RETURN BACK | Back |
| M/A | M/A | HOME SMART | Smart |
| TELETEXT | Teletext | REPEAT TEXT | Text |
| EXIT | Exit | CLEAR EXIT | Exit |
| MENU | Menu | TOP MENU MENU | Menu |
| FAV | FAV | FAV PRE-CH | Pre Ch |
| P/L | P/L | APP MEDIA | Media |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | Ok |
| | Right | | Right |
| | Down | | Down |
| | Vol + | + VOL | Vol + |

| Original | | Replacement | |
|---|---|---|---|
| | Vol - | VOL – | Vol - |
| PG+ | PG+ | + CH | Ch + |
| PG- | PG- | CH – | Ch - |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |

https://all-remote-controls.nl/en/1060334-48281-replacement-remote-control-for-REMCON278.html