Mandis shop

RC-970

Original	Replacement	Original	Replacement
Power	Power	Volume-	Vol -
FM/AM	TV/R	Muting	Mute
Stop	Stop	Treble+	Up
Play	Play	Treble-	Down
Pause	Pause	Bass+	Right
>>I/Tuning Up	>>I	Bass-	Left
I<</Tuning	I<<		
MP3 Folder/Preset Up	Ch +		
MP3 Folder/Preset Down	Ch -		
Function (Tuner/CD/AUX)	Menu		
Sleep	Sleep		
MP3	Dual		
PTY Repeat	Text		
RDS Shuffle	Smart		
Memory/Clock Set	Media		
Timer	AV		
Volume+	Vol +		

https://all-remote-controls.nl/en/Teac/1061255-31525-replacement-remote-control-for-Teac-RC-970.html