Mandis shop

LG AKB73855901

Original		Replacement	
	Power		Power
	Bluetooth	BLUETOOTH 9	9
VOL +	Vol +	VOL +	Vol +
*	*	LIST SMART	Smart / List
OPTICAL	Optical	MEDIA DISPLAY	Display / Media
VOL -	Vol -	VOL -	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
LG TV	LG Tv	TV 1	1
WOOFER LEVEL +	Woofer Level +		Up
WOOFER LEVEL -	Woofer Level -		Down
ON 3D SOUND	3D Sound On	TUNE-	<< / Tune-
3D OFF SOUND	3D Sound Off	TUNE+	>> / Tune+
ON DRC	DRC On	PRESET-	I<< / Preset-
DRC OFF	DRC Off	PRESET+	>>I / Preset+
	Power Tv	SHIFT +	Shift + Power
ON AUTO POWER	Auto Power On	SLOW	Play / Slow
AUTO OFF POWER	Auto Power Off	STEP-FREEZE	Pause / Step / Freeze

Original		Replacement	
AV / INPUT	AV Input Tv	RDS AV INPUT	AV / Input / RDS
PR/CH	PR/CH+ Tv	CH PAGE +	CH+ / Page+
VOL +	Vol + Tv	SHIFT + VOL +	Shift + Vol +
	Mute Tv	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
PR/CH	PR/CH- Tv	CH PAGE -	CH- / Page-
VOL -	Vol - Tv	SHIFT + VOL -	Shift + Vol -

https://al-remotecontrols.nl/en/LG-AKB73855901-replacement-remote-control-for-LG-AKB73855901.html