Mandis shop

KPT2000

Original		Replacement	
	Power		Power
MODE	Mode	FORMAT PICTURE	Picture / Format
SET	Set	HOME MENU	Menu / Home
+	+	+ VOL	Vol+
-	-	VOL -	Vol-
.:I	.:I	OPT-TOOLS SETUP	Setup / OPT /
ION	ION	LIST SMART	Smart / List
(=	(=	MEDIA DISPLAY	Display / Media

Original	Replacement

https://all-remote-controls.nl/en/Equation/1064811-93310-replacement-remote-control-for-Equation-KPT-2000.html