Mandis shop

REMCON1571

Original		Replacement	
	Power		Power
sleep	Sleep	TIMER SLEEP	Sleep / Timer
iPod	iPod	APP REPEAT	Green / APP / Repeat
aux	AUX	NETFLIX SEARCH	Red / Netflix / Search
am	AM	YouTube REPEAT A-B	Yellow / YouTube / Repeat
fm	FM	Prime Video RANDOM	Blue / Prime Video / Random
	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	>>I	PRESET+	>>I / Preset+
	Vol+	VOL +	Vol+
	Vol-	VOL −	Vol-
	((·))	LIST SMART	Smart / List
	Mute	DIMMER MUTE	Mute / Dimmer
	▲		Up
	▼		Down
select	Select	OK	OK

Original		Replacement	
menu	Menu	HOME MENU	Menu / Home

https://all-remote-controls.nl/en/LOGITECH/1065263-90767-replacement-remote-control-for-LOGITECH-REMCON1571.html