Mandis shop

RC- 420

Original	Replacement
Phone	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
DNPP/SBF	Stop / Hold
I<< Tune Track	I<< / Preset-
>>I Tune Track	>>I / Preset+
ATT	Eject / Surround
SRC	AV / Input / RDS
FM/Disc+/#	Up
ANG	Info / Angle
Direct/OK	OK
AM/Disc-/*	Down
Vol +	Vol +
Vol -	Vol -
1	1
2	2
3	3

Original	Replacement
4	4
5	5
6	6
7	7
8	8
9	9
0	0

https://al-remotecontrols.nl/en/kenwood/167357-replacement-remote-control-for-kenwood-rc-420-a02550.html