Original		Replacement	
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
DVD/CARD	DVD/CARD	PROGRAM TV/RADIO	TV/Radio /
STANDBY/ON	Standby/On		Power
TV1 1	1	TV 1	1
TV2 2	2	DVD 2	2
TV3 3	3	CD-STB 3	3
TV4 4	4	VIDEO 4	4
TV5 5	5	TAPE 5	5
TV6 6	6	TUNER 6	6
TV7 7	7	AUX-HDD 7	7
TV8 8	8	USB 8	8
TV9 9	9	BLUETOOTH 9	9
TV+/- 10	10	-/-- GUIDE EPG	Guide / EPG / -/--
TV0 0	0	HDMI-SAT 0	0
MUTING +10	+10	PC FAV MARKER	Fav / Marker / PC
RETURN	Return	RETURN BACK	Back / Return
THUMBNAIL /LIST	Thumbnail / List	FORMAT PICTURE	Picture / Format

Original		Replacement	
TITLE/GROUP	Title/Group	GOTO TEXT	Text / Goto
TV/VIDEO CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
CH+	Up		Up
MENU	Menu	HOME MENU	Menu / Home
VOL-	Left		Left
ENTER	Enter	OK	OK
VOL+	Right		Right
CHOICE	Choice	LIST SMART	Smart / List
CH-	Down		Down
ON SCREEN	On Screen	MEDIA DISPLAY	Display / Media
PREVIOUS	I<<<Previous	PRESET-	I<< / Preset-
NEXT	>>I / Next	PRESET+	>>I / Preset+
CLEAR	Stop/Clear	HOLD	Stop / Hold
CLEAR	Stop/Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
SELECT	Play/Select	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Replacement		Original	Replacement
SLOW -	<</ Slow-	TUNE-	<< / Tune-		
SLOW +	>>/ Slow+	TUNE+	>> / Tune+		
	←	NETFLIX SEARCH	Red / Netflix / Search		
SOUND EFFECT	Sound Effect	TITLE SOUND	Sound / Title		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
VFP	VFP	OPT-TOOLS SETUP	Setup / OPT /		
ANGLE	Angle	ANGLE INFO	Info / Angle		
SUB TITLE	Sub Title	EQ SUBTITLE	Subtitle / EQ		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
AMP VOL +	AMP Vol +	VOL +	Vol +		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
SLIDE EFFECT	Slide Effect	TIMER SLEEP	Sleep / Timer		
DIMMER	Dimmer	DIMMER MUTE	Mute / Dimmer		
AMP VOL -	AMP Vol -	VOL -	Vol -		

Original	Replacement
Standby/ON Tv	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
-/--	Guide / EPG / -/--
0	0
Muting	Mute / Dimmer
Tv/Video	AV / Input / RDS
Up	Up
CH+	CH+ / Page+
Left	Left

Original	Replacement
Vol -	Vol -
Right	Right
Vol +	Vol +
Down	Down
CH-	CH- / Page-