Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
PIP/Audio	3D
[<>]	Format
?	Smart
Mute	Mute
Z/Disc Menu	Menu
i/OSD	Info

Original	Replacement
TXT	Text
TV-G	Guide
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
P+	Ch +
P-	Ch -
Vol +	Vol +
Vol -	Vol -
Red/Image/I>	Red
Green/Timer	Green
Yellow/@	Yellow
Blue/Sound	Blue
Play	Play
Pause	Pause

Original		Replacement	
	Stop		Stop
TXT	<<		<<
TV-G	>>		>>
?	I <		I <<
	>I		>>I

Original	Replacement

Original	Replacement	Original	Replacement
Power	Power	Z/Disc Menu	Menu
1	1	Up	Up
2	2	Down	Down
3	3	Right	Right
4	4	Left	Left
5	5	OK	Ok
6	6	P+	Ch +
7	7	P-	Ch -
8	8	Vol +	Vol +
9	9	Vol -	Vol -
0	0	Red/Image/I>	Red
PIP/Audio	3D	Green/Timer	Green
[<>]	Format	Yellow/@	Yellow
?	Smart	Blue/Sound	Blue
i/OSD	Info	Play	Play
TXT	Text	Pause	Pause
TV-G	Guide	Stop	Stop

Original	Replacement	Original	Replacement
TXT <<	<<		
TV-G >>	>>		
>I	>>I		
? I <	I <<		

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
PIP/Audio	3D
[<>]	Format
?	Smart
Mute	Mute
i/OSD	Info
TXT	Text

Original	Replacement
Z/Disc Menu	Menu
TV-G	Guide
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
P+	Ch +
P-	Ch -
Vol +	Vol +
Vol -	Vol -
Red/Image/I>	Red
Green/Timer	Green
Yellow/@	Yellow
Blue/Sound	Blue
Play	Play
Pause	Pause

Original		Replacement		Original	Replacement
	Stop		Stop		
	<<		<<		
	>>		>>		
	I <		I <<		
	>I		>>I		

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
PIP/Audio	3D
[<>]	Format
?	Smart
i/OSD	Info
TXT	Text
TV-G	Guide

Original	Replacement
Z/Disc Menu	Menu
P+	Ch +
P-	Ch -
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
Red/Image/I>	Red
Green/Timer	Green
Yellow/@	Yellow
Blue/Sound	Blue
Play	Play
Pause	Pause
Stop	Stop

Original	Replacement	Original	Replacement
<<	<<		
>>	>>		
I <	I <<		
>I	>>I		