Original	Replacement
AVR/AVC On	Power
AVR/AVC Off	Shift + Power
Power Tv	TV/R
Power VCR	Smart
Power DVD/VDP	Media
PHONO	1
CD	2
DVD/VDP	3
VCR-1	4
VCR-2 / V. AUX	5
TV/DBS	6
MD/Tape Mon	7
Tuner	8
Shift	9
Video Select	0
Input Mode	Guide
Surround Mode	Pre Ch

Original	Replacement
<< Deck-VCR	Shift + <<
< Deck-VCR	Shift + Play
Deck-VCR >	Shift + Pause
Deck-VCR >>	Shift + >>
Stop Deck-VCR	Shift + Stop
CH+	Ch +
CH-	Ch -
Disc Skip+	Blue
Play CD/MD/CDR-DVD/	Play
Stop CD/MD/CDR-DVD/	Stop
Pause CD/MD/CDR-DVD/	Pause
CD/MD/CDR-DVD/ VDP >>I	>>I
I << CD/MD/CDR-DVD/	I <<
CD/MD/CDR-DVD/ VDP >>	>>
<< CD/MD/CDR-DVD/	<<
System/Setup	Menu
Surround/Menu	D. Menu

Original		Replacement		Original	Replacement
T.TONE RETURN	T. Tone/ Return	RETURN BACK	Back		
STATUS DISPLAY	Status/ Display	DISPLAY INFO	Info		
▲	Up	▲	Up		
▼	Down	▼	Down		
▶	Right	▶	Right		
◀	Left	◀	Left		
CH.SELECT SELECT	CH. Select/ Select	OK	Ok		
MASTER VOL ▲	Master Volume	+ VOL	Vol +		
MASTER VOL ▼	Master Volum	VOL −	Vol -		
MUTING	Muting	MUTE	Mute		
VOLUME ▲	Tv Vol +	SHIFT +	+ VOL Shift + Vol +		
VOLU ▼	Tv Vol -	SHIFT +	VOL − Shift + Vol -		
CHANNEL +	Tv CH+	SHIFT +	+ CH Shift + Ch +		
CHAN −	Tv CH-	SHIFT +	CH − Shift + Ch -		

Original	Replacement	Original	Replacement
AVR/ AVC On	Power		
AVR/ AVC Off	SHIFT + Shift + Power		
Play CD/ MD/ CDR- DVD/	PLAY MODE Play		
Pause CD/ MD/ CDR- DVD/	Pause		
Stop CD/ MD/ CDR- DVD/	Stop		
CD/ MD/ CDR- DVD/ VDP >>I	>>I		
I << CD/ MD/ CDR- DVD/	I <<		
CD/ MD/ CDR- DVD/ VDP >>	>>		
<< CD/ MD/ CDR- DVD/	<<		

Original	Replacement
AVR/AVC On	Power
AVR/AVC Off	SHIFT + Power: Shift + Power
CH+	Ch +
CH-	Ch -
Deck-VCR >>	>>
<< Deck-VCR	<<
Deck-VCR >	SHIFT + Pause: Shift + Pause
Stop Deck-VCR	SHIFT + Stop: Shift + Stop
Title CD/MD/CDR-DVD/	Exit
Disc Skip+ CD/MD/CDR-DVD/	Blue
Play CD/MD/CDR-DVD/	Play
Pause CD/MD/CDR-DVD/	Pause
Stop CD/MD/CDR-DVD/	Stop
CD/MD/CDR-DVD/ VDP >>I	>>I
I << CD/MD/CDR-DVD/	I <<
System/Setup	Menu
Surround/Menu	D. Menu

Original	Replacement
T.Tone/Return	Back
Status/Display	Info
Up	Up
Down	Down
Right	Right
Left	Left
CH.Select/Select	Ok