Mandis shop

JVC RM-SUXGN5R

Original	Replacement
Power	Power
Eco/Dimmer	Shift + Mute / Dimmer
Display	Display / Media
Clock	Setup / OPT /
AutoSTBY	Back / Return
Tuner Mode	Smart / List
Delete	D.Menu / Top
Sleep	Sleep / Timer
Timer	Shift + Sleep / Timer
Cancel	Exit / Cancel / Clear
Repeat	Green / APP / Repeat
Random	Blue / Prime Video / Random
Program	TV/Radio /
Up	Up
I<<	I<< / Preset-
Play/Pause CD	Play / Slow
>>I	>>I / Preset+

Original	Replacement
Tuner	6
Play/Pause USB	Pause / Step / Freeze
SET	OK
Down	Down
<<	<< / Tune-
>>	>> / Tune+
Sound Mode	Sound / Title
Audio In	Audio / Lang I/II
Volume+	Vol +
Volume-	Vol -
Stop/PTY	Stop / Hold
Fade Muting	Mute / Dimmer
Audio Inlevel	Yellow / YouTube / Repeat
HBS	Info / Angle
Sound Turbo	Red / Netflix / Search

https://al-remotecontrols.nl/en/JVC-10423-761-replacement-remote-control-for-JVC-RM-SUXGN5R-10423-761.html