Mandis shop

LG AKB73616006

Original		Replacement		Original		Replacement	
Start	Start		Power				
Home	Home		Menu / Home				
Mode	Mode		Setup / OPT /				
Turbo	Turbo		Smart / List				
	Up		Up				
	Left		Left				
Stop OK	Stop/OK		OK				
Stop OK	Stop/OK		Stop / Hold				
	Right		Right				
	Down		Down				
Repeat	Repeat		Green / APP / Repeat				
My Space	My Space		Display / Media				
	Nothing 1		1				
Mute	Mute		Mute / Dimmer				
	Nothing 2		2				
Diagnosis	Diagnosis		D.Menu / Top				

https://all-remote-controls.nl/en/LG/1068089-77844-replacement-remote-control-for-LG-AKB73616006.html