Mandis shop

Philips 996580000939

Original		Replacement	
	Power		Power
AUX	AUX	TIMER AV	AV
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
AUDIO IN	Audio In	SOUND DUAL	Dual
COAX	Coax	DISC NAV LIST	List
OPTICAL	Optical	TOP MENU MENU	Menu
	Play	PLAY MODE	Play
	Pause		Pause
	I<		I<<
	>I		>>I
USB	USB	SEARCH TV/R	TV/R
VOLUME +	Vol +	VOL +	Vol +
VOLUME −	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
BASS +	Bass+		Up
BASS −	Bass-		Down
TREBLE +	Treble+	CH +	Ch +

Original		Replacement	
TREBLE −	Treble-	CH −	Ch -
SURR ON	Surr On		Right
SURR OFF	Surr Off		Left

https://al-remotecontrols.com/Philips/1369-653-replacement-remote-control-for-Philips-Soundbar-Speaker-996580000939.htm