Mandis shop

Pioneer PWW1168

Original	Replacement
Power	Power
Hi-Lite	Smart
Previous	Back
Best	Menu
Repeat	Text
Mode	Media
Program	Sleep
Clear	Exit
Display	Info
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8

Original	Replacement
9	9
0	0
Track	Pre Ch
Disc	Guide
Disc+	Ch +
Disc-	Ch -
>>I	>>I
I <<	I <<
>>	>>
<<	<<
Stop	Stop
Pause	Pause
Play	Play
Random	Format

https://al-remotecontrols.com/Pioneer/1545-245-replacement-remote-control-for-Pioneer-PWW1168.htm