Mandis shop

RT8100

Original	Rechange	Original	Rechange
Standby	Power	Down	Down
Mute	Mute	Right	Right
P/N	Smart	Left	Left
Open/Close	Eject	OK	Ok
<<	<<	Vol +	Vol +
>>	>>	Vol -	Vol -
Play/Pause	Play	1	1
Stop	Stop	2	2
I<<	I<<	3	3
>>I	>>I	4	4
Setup	Options	5	5
Source	AV	6	6
Info	Info	7	7
Return/Exit	Exit	8	8
CH+	Ch +	9	9
CH-	Ch -	0	0
Up	Up	Slow	Back

Original	Rechange	Original	Rechange
Goto	Media		
Program	Sleep		
Title/TTX	Text		
Audio	Dual		
Subtitle	Subt		
Red/Repeat	Red		
Green/A-B	Green		
Yellow/Menu	Yellow		
Blue/Angle	Blue		
EPG	Guide		
Favorite	Pre Ch		
Tv/Radio	TV/R		
Zoom	Shift + Eject		