Mandis shop

JVC RM-MH15G

Original	Rechange
Stand By	Shift + Power
On	Power
HDMI 1	1
HDMI 2	2
COMP	3
3D Format	Picture / Format
3D Setting	Setup / OPT /
Anamo	9
Lens Control	Smart / List
Lens Memory	Display / Media
Lens AP.	0
Hide	TV/Radio /
Light	Zoom / Size
Up	Up
Left	Left
OK	OK
Right	Right

Original	Rechange
Down	Down
Menu	Menu / Home
Back	Back / Return
Film	4
Cinema	5
Anime	6
Natural	7
Stage	8
3D	Subtitle / EQ
User	Guide / EPG / -/--
Info	Info / Angle
C.M.D.	Fav / Marker / PC
Gamma	Text / Goto
Color Temp	Audio / Lang I/II
Color Space	Blue / Prime Video / Random
Pic Adj.	AV / Input / RDS

https://al-remotecontrols.fr/JVC-RM-MH15G-telecommande-de-replacement-pour-JVC-RM-MH15G.htm