Original	Rechange
Standby	Power
Mute	Mute
P/N	Smart
Open/Close	Eject
<<	<<
>>	>>
Play/Pause	Play
Stop	Stop
I<<	I<<
>>I	>>I
Setup	Options
Source	AV
Info	Info
Return/Exit	Exit
CH+	Ch +
CH-	Ch -
Up	Up

Original	Rechange
Down	Down
Right	Right
Left	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Slow	Back

Original	Rechange	Original	Rechange
Goto	Media		
Program	Sleep		
Title/TTX	Text		
Audio	Dual		
Subtitle	Subt		
Red/Repeat	Red		
Green/A-B	Green		
Yellow/Menu	Yellow		
Blue/Angle	Blue		
EPG	Guide		
Favorite	Pre Ch		
Tv/Radio	TV/R		
Zoom	SHIFT + ZOOM Shift + Eject		