Mandis shop

RC021801

Original		Rechange	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STANDBY	Standby		Power
MASTER VOLUME-	Master Volume-	VOL –	Vol -
MASTER VOLUME +	Master	+ VOL	Vol +
BASS +	Bass+	+ CH PAGE	CH+ / Page+
FRONT FADE	Fade Front	LIST SMART	Smart / List
TREBLE +	Treble+	▲	Up
BASS –	Bass-	CH PAGE –	CH- / Page-
FADE REAR	Fade Rear	MEDIA DISPLAY	Display / Media
TREBLE –	Treble-	▼	Down
POP	Pop	AUX - HDD 7	7
CLASSIC	Classic	USB 8	8
ROCK	Rock	BLUETOOTH 9	9
MOVIE	Movie	VIDEO 4	4
STEREO	Stereo	TAPE 5	5
CONCERT	Concert	TUNER 6	6
INPUT 1 5.1	Input 1/5.1	TV 1	1

Original		Rechange	
INPUT 2	Input 2	DVD 2	2
INPUT 3	Input 3	CD - STB 3	3

https://al-remotecontrols.fr/Philips/1662-852-telecommande-de-replacement-pour-Philips-RC021801-3128802.htm