Mandis shop

Sanyo CXVT

Original	Rechange
Standby	Power
Lamp/Lamp	Shift + Video Comp (Shift + Comp / Video)
NO Show	Source
Freeze	Timer Freeze
Menu	Menu
Reset	Shift + Power (Shift + Power)
Screen	Aspect Eco
Image	Auto
Up	Up
Down	Down
Right	Right
Left	Left
OK	Enter
Brightness	Shift + Aspect Eco (Shift + Eco / Aspect)
Contrast	Invert 3D
Color	Focus Volt
Lens Iris	Mute Blank

Original	Rechange
Preset Image	Stop - (- / Stop)
User Image	Video Comp (Comp / Video)
Video	Mode
Component/C1/	Page▲ Vol (Vol + / Page +)
HDMI/H1/H2	Play + (+ / Play)
S-Video	Page▼ Vol (Vol - / Page -)
PC	Shift + Mode (Shift + Mode)
Info	Info Help (Help / Info)

https://al-remotecontrols.fr/Sanyo/1602-265-telecommande-de-remplacement-pour-Sanyo-CXVT-9508745.htm