Mandis shop

RB- DA1000

Original		Rechange	
⏻/ON	On	⏻	Power
SLEEP	Sleep	PROG SLEEP	Sleep
FUNCTION	Function	TOP MENU MENU	Menu
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PRESET	Preset	HOME SMART	Smart
TUNER /BAND	Tuner / Band	SEARCH TV/R	TV/ R
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -

Original		Rechange	
▶/II	Play/ Pause	PLAY MODE ▶	Play
■	Stop	■	Stop
▶▶I	>>I / Tune+	>>I	>>I
I◀◀	I <</ Tune-	I<<	I <<
MEMORY	Memory	REC MODE ●	Rec
FM MODE /REPEAT	FM	REPEAT TEXT	Text

https://all-remote-controls.nl/fr/Sanyo/1635-9489-telecommande-replacement-pour-Sanyo-RB-DA1000.htm